



How To Remove the Battery Back Plate

This is a step-by-step guide on how to remove the battery back plate on JVC GR-D290U camera.

Written By: justin chen





TOOLS:

- [Phillips #1 Screwdriver](#) (1)
-

Step 1 — Battery Back Plate



- Remove 2 screws on the underside of camera eyepiece.

Step 2



- Remove 2 screws connecting back plate to camera base.

Step 3



- Remove back plate.

This document was last generated on 2017-06-18 05:41:12 AM.